

CAN DI 测试操作 (CAN DI test Operation)

注明：先确定（OBD 接头` OBD 主线` CAN DI `GM 主机` 供电电源）之间的连接是否正确。

!! 测试 CAN DI 时电源要从 ODB 接头输入。

Pay attention: firstly be sure the connections among obd connector, obd main cables, and CAN DI `GM main engine power supply are right.



1.




2.



3.




4.



5.




6.



7.



A screenshot of a blue screen displaying the results of a CANdi self-test. The title is 'CANdi Self Test Results'. Below the title, it says 'Test Complete' and 'Test status'. The results are listed in two columns: the test item on the left and the status on the right. The items include CANdi Present, Boot S/W Revision, App. S/W Revision, Hardware Revision, CANdi RAM, CANdi Boot, CANdi Resident, CANdi Application, Low Speed Data Link, Med. Spd. Data Link, and High Speed Data Link. All items show a 'Pass' status.

Test Complete	Test status
CANdi Present	Pass
Boot S/W Revision	1.60
App. S/W Revision	4.50
Hardware Revision	1.00
CANdi RAM	Pass
CANdi Boot	Pass
CANdi Resident	Pass
CANdi Application	Pass
Low Speed Data Link	Pass
Med. Spd. Data Link	Pass
High Speed Data Link	Pass

10.

注明：CAN DI 有两项测试，测试结果以上图 8 号 10 号为准!!! (Notice: there are two test results. Like picture 8 and picture 10)